







MONTAGEVOORSCHRIFT  
MONTAGE-ANLEITUNG

MOUNTING INSTRUCTIONS  
INSTRUCTIONS DE MONTAGE







HANDDOEKBEUGEL VR-X



MONTAGEVOORSCHRIFT  
MONTAGE-ANLEITUNG

MOUNTING INSTRUCTIONS  
INSTRUCTIONS DE MONTAGE

HANDDOEKBEUGEL VR-X



X=Type VR paar buizen (189mm)  
X=Typ VR paarige Rohre (189mm)  
X=Type VR des tubes pairs (189mm)  
X=Type VR even tubes (189mm)

X=Type VR onpaar buizen (207mm)  
X=Typ VR nicht paarige Rohre (207mm)  
X=Type VR des tubes impairs (207mm)  
X=Type VR unpaired tubes (207mm)

X=Type VRS (185mm)  
X=Typ VRS (185mm)  
X=Type VRS (185mm)  
X=Type VRS (185mm)